

Westform

Meta

Best Way Roofers Supply
 7-2720 Hwy 97 N, Kelowna, V1X4J7
 Tel: 250-763-4405 Fax: 250-763-9455
 Toll Free: 1-800-663-5450
www.bestwayrooferssupply.com



White White • QC 8317



Surf White • QC 8316



Brite White • QC 8783



Bone White • QC 8273



Regent Grey • QC 8730



Ascot Grey • QC 8683



Stone Grey • QC 8305



Charcoal Grey • QC 8306



Black • QC 8262



Black Coffee • QC 8326



Metro Brown • QC 8228



Brite Red • QC 8386



Tile Red • QC 8259



Dark Red • QC 8250



Ivory • QC 8802



Sportsman Yellow • QC 8319



International Orange • QC 8234



Gold • QC 8276



Tan • QC 8315



Slate Blue • QC 8260



Sapphire Blue • QC 8261



Royal Blue • QC 8790



Heron Blue • QC 8330



Melchers Green • QC 8307

Kynar® Colours



Brite Green



Pacific Turquoise • QC 8258



Turquoise • QC 8310



Deep Water Green • QC 8684



Snow Drift White - Kynar®



Tahoe Blue - Kynar®



Dark Green - Kynar®



Colonial Red - Kynar®



Terra - Cotta - Kynar®



Dark Bronze - Kynar®



Weathered Copper - Kynar®

IMPORTANT NOTE ON COLOUR MATCHING

Colour can vary between different paint batches and production runs on painting lines. Furthermore, over extended periods, the colour of originally installed panels will weather and therefore vary from replacement panels and panels for new additions.

COLOURS SHOWN ARE PRINTED APPROXIMATIONS OF ACTUAL PAINTED PRODUCT AND MAY VARY.

Westform

Metals

MAINTENANCE

A thorough building clean up after completion of construction should be conducted to remove all debris, metal filings, metal fines, etc. from walls and roofs.

For low slope roofs an annual inspection should be conducted to remove accumulated debris (i.e. leaves and branches) and to detect any signs of possible coating deterioration.

Regular washing of pre-finished steel can extend service life and maintain the appearance of the finish. This should be part of the building maintenance program and be done in the spring. Washing with clear water (hose or light pressure sprays) is often sufficient.

Solvents and abrasive cleaners should be avoided. Caulking compounds oils, greasers, tars, wax and similar substances can be removed with mineral spirits applied only to the affected areas. Cleaning and a thorough rinsing with water should follow the use of the mineral spirits.

TRANSPORTATION

If material is to be moved in wet or snow conditions, product must be tarped to prevent moisture penetration.

STORAGE

Material not being installed right away: condensation and water penetration will create white rust and could cause the paint to lift from pre-printed metal.

It is recommended and preferred that a dry area be used, or covered with a provision for air circulation. Do not use plastic.

To prevent corrosion, it is further recommended that material be kept away from salts, cement and fertilizers.

If bundled material should become wet, it is recommended that you separate material immediately and wipe dry.